



IMPORTANT INSTALLATION INSTRUCTIONS TC-H6SM05-S2

Remove the stock rubber inlet from the air box and replace with the DNA stage 2.
After installing the DNA STG2 inlet, apply 4 drops of glue in order to secure in place (see diagram).
The Stage 2 airbox inlet for the Honda FMX 650 is designed by DNA to work in cooperation with a DNA high performance filter P-H6SM05-01 and the Dynojet Carburetor recalibration kit E1193 that you will have to purchase separately for the complete Honda FMX Stage 2 application.

ATTENTION ! If used without the Dynojet kit installed the bike will run lean and possible damage will occur.

ΣΗΜΑΝΤΙΚΕΣ ΟΔΗΓΙΕΣ ΤΟΠΟΘΕΤΗΣΗΣ ΤΟΥ TC-H6SM05-S2

Αφαιρέστε την εργοστασιακή λαστιχένια εισαγωγή και στην θέση της τοποθετήστε την DNA στάδιο 2.
Αφού έχετε τοποθετήσει την εισαγωγή DNA σταδιο2 στην θέση της, απλώστε 4 σταγόνες κόλλα για να την ασφαλίσετε όπως δείχνει το διάγραμμα.
Η εισαγωγή στάδιο 2 για Honda FMX 650 της DNA είναι σχεδιασμένη για να λειτουργήσει σε συνεργασία με το φίλτρο υψηλής απόδοσης της DNA P-H6SM05-01 και το κιτ DYNOJET E1193.

ΠΡΟΣΟΧΗ ! Εάν χρησιμοποιηθεί χωρίς το κιτ της Dynojet η μηχανή θα λειτουργήσει με φτωχό μείγμα και θα έχει σαν αποτέλεσμα την φθορά του κινητήρα.

