

12Vdc

250

keeloq 64 bit.

1. AUTO LEARN
 2. led 10
 - 3.
 4. led
- 10
- 250

1. AUTO LEARN led
- 2.

DIP SWITCH	POSITION	OPERATION	DESCRIPTION
1	OFF	ELECTRIC STRIKE	Output command for connection with electric strike
1-2	ON - OFF	ELECTRIC BOLT	Provides power to the electric bolt when you press the button or remote control
	ON - ON		Turns power off to the electric bolt when you press the button or remote control
3	OFF	OPERATION TIME	Enables the output while you press the button or remote control
			Enables the output for 4 seconds after you release the button or remote control
4	OFF	CHANNEL SELECT	Independent operation of 2 outputs
			Single button or remote control command enables both outputs

S5070-KR 1 CH is suitable for any door where an electric lock is installed and there is a need for remote control. It has 2 independent outputs so that we connect 2 electric locks operating separately from one another. It can be connected with external button, intercom, call center, card reader and keyboard or fingerprint reader. It has a 12 Vdc battery input so that in case of power failure, the systems continues working and built in electric charger for lead battery. The control board can store up to 250 rolling keeloq 64 bit coded remote controls.

Remote control programming

1. Press AUTO LEARN once to the channel you want to program.
2. The RED light turns on for 10" seconds (programming time).
3. Press the button of the remote control you want to program.
4. The RED button starts blinking. The remote control has been programmed.

When during the 10" seconds of programming time no button is pressed then the programming LED turns off and the receiver returns to its normal state.

If all 250 different codes have been programmed and you try to repeat the above procedure, no other code can be stored to memory.

Remote control deleting

1. Hold AUTO LEARN pressed for any channel until the RED programming LED starts blinking.
2. Then release the button and all programmed remote controls off the channels have been deleted.

DIP SWITCH	POSITION	OPERATION	DESCRIPTION
1	OFF	ELECTRIC STRIKE	Output command for connection with electric strike
1-2	ON - OFF	ELECTRIC BOLT	Provides power to the electric bolt when you press the button or remote control
	ON - ON		Turns power off to the electric bolt when you press the button or remote control
3	OFF	OPERATION TIME	Enables the output while you press the button or remote control
			Enables the output for 4 seconds after you release the button or remote control
4	OFF	CHANNEL SELECT	Independent operation of 2 outputs
			Single button or remote control command enables both outputs

